



VIDEO TUTORIAL


Important!

This replacement procedure can be used for:

VW CADDY III Box (2KA, 2KH, 2CA, 2CH) 2.0 TDI, VW CADDY III Estate (2KB, 2KJ, 2CB, 2CJ) 2.0 TDI, VW EOS (1F7, 1F8) 2.0 TDI, VW GOLF PLUS (5M1, 521) 2.0 TDI, VW GOLF V (1K1) 2.0 TDI, VW GOLF V (1K1) 2.0 TDI 4motion, VW GOLF V Variant (1K5) 2.0 TDI, VW JETTA III (1K2) 2.0 TDI, VW TOURAN (1T1, 1T2) 2.0 TDI

The steps may slightly vary depending on the car design.

REPLACEMENT: ANTI ROLL BAR LINKS – VW TOURAN 1T1 1T2. TOOLS YOU NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #17
- Combination spanner #19
- Drive socket # 19
- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Wheel chock

AUTODOC recommends:

- Replace the stabiliser links on VW Touran 1T1 1T2 in pairs.
- The replacement procedure is identical for both stabiliser links on the same axle.
- All work should be done with the engine stopped.

REPLACEMENT: ANTI ROLL BAR LINKS – VW TOURAN 1T1 1T2. USE THE FOLLOWING PROCEDURE:

1



Secure the wheels with chocks.

2



Loosen the wheel mounting bolts. Use wheel impact socket #17.

3



Raise the front of the car and secure on supports.

4



Unscrew the wheel bolts.

AUTODOC recommends:

- Important! Hold the wheel while unscrewing the fastening bolts. VW Touran 1T1 1T2

5



Remove the wheel.

6



Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.

7



Unscrew the fastener connecting the stabilizer link to the shock strut. Use a drive socket #19. Use a ratchet wrench.

8



Unscrew the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #17. Use a combination spanner #19.

9



Remove the stabilizer rod.

Replacement: anti roll bar links – VW Touran 1T1 1T2.
Professionals recommend:

- Examine stabiliser bushes. Replace them if needed.

10



Install a new rod, tighten the fasteners.

11



Tighten the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #17. Use a drive socket #19. Use a torque wrench. Tighten it to 60 Nm torque.

12




Tighten the fastener connecting the stabilizer link to the shock strut. Use a combination spanner #17. Use a drive socket #19. Use a torque wrench. Tighten it to 60 Nm torque.

13



Treat all joints of the stabiliser link. Use copper grease.

14



Treat the surface where the brake disc contacts the wheel rim. Use copper grease.

15



Clean the brake disk surface. Use a brake cleaner.

AUTODOC recommends:

- Replacement: anti roll bar links – VW Touran 1T1 1T2. After applying the spray, wait a few minutes.

16



Install the wheel.

AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. VW Touran 1T1 1T2

17



Screw in the wheel bolts. Use wheel impact socket #17.

18



Lower the car and working in a cross order, tighten the wheel bolts. Use a torque wrench. Tighten it to 120 nm torque.

19



Remove the jacks and chocks.

**DID YOU FIND THESE INSTRUCTIONS
HELPFUL?**

YES

NO



BECOME A MEMBER OF AUTODOC CLUB!

AUTODOC — TOP QUALITY AND AFFORDABLE CAR
PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR



BUY SPARE PARTS FOR VW



ANTI ROLL BAR LINKS: A WIDE SELECTION



CHOOSE CAR PARTS FOR VW TOURAN 1T1 1T2



ANTI ROLL BAR LINKS FOR VW: BUY NOW



ANTI ROLL BAR LINKS FOR VW TOURAN 1T1 1T2: THE BEST DEALS & OFFERS



Disclaimer:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AutoDoc shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AutoDoc shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AutoDoc shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AutoDoc strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2018 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by Autodoc GmbH.